

Using instructions:

Please read this instruction carefully before using this furniture. Things of notice:

- Don't put furniture directly under sunlight or near AC vent or radiator to avoid color fading, shedding edge band or distortion.
- Don't tilt desk or chair to avoid broken feet or loose connection.
- Don't put hot or icy objects directly on it to avoid color change or indelible marks.
- Don't push items on furniture directly to avoid scratches.
- Lift the furniture for about 10 mm off the ground when it has to be removed as a whole to avoid possible damages to the bottom and connector part.
- It is suggested to put a soft cloth underneath if you want to lay heavy or hard items on the furniture.
- Use a soft cotton cloth or feather duster for cleaning and maintenance.
- Use detergent specially designed for furniture instead of chemical detergent or acid liquid for removing lampblack and other stains.

Simple malfunction solution

Remove stains


- paper mark: Immerse paper in salad oil and wait several minutes. Wipe the furniture with furniture-used steel wool along the grain and then polish it.
- food stain: Tea, vegetable, fruit, butter leaves slight traces on the surface and it should be wiped out immediately.
- paint: For water-based paint, use soft and wet cloth to wipe it; for oil paint, let it dry up naturally and gently shave it with a blunt spatula or hard cards.
- nail polish/nail polish remover: As a chemical solvent, it should be wiped immediately.
- alcohol: If perfume/cocktail/medicine liquid spills out, let it dry up naturally.
- chewing gum: Shave it with blunt spatula or hard card after cooling it with ice bag or cold water.
- ball-pen/ink mark: Use soft eraser to rub it or sprinkle several drips of water. Avoid chemical solvent with alcohol or with high corrosive ability.
- suggestion: Furniture-used steel wool can be bought at building material & hardware stores. (Don't use kitchen steel wool).
- note: The above suggestions may bring different results due to different operations of each person. It would be better if you can test it in an inconspicuous area first.
- There may be some cases as listed after long time of using. Please refer to correspondent measures.
- If your product is updated, please hand old products to qualified recycling companies.

Malfunction	Reason	Solution
The banding edge is loose	Improper environment	Use hairdryer or iron to melt the glue and then stick it at once
Drawers can't be pulled out smoothly	Lubricating oil is drying up	Add lubricating oil or wax to the slide
Uneven desktop	The adjustment leg is not properly set up	Fix the adjustment leg
Sliding door slides out of the side panel	Sliding door positioning parts are loose or top bead slides down	Restore the sliding door positioning parts and top beads to original positions

Assembly instructions:

- Please determine the location of your furniture before assembly to avoid moving them for a large distance after being assembled.
- Do not place your furniture in dark and damp or hot and dry environment.
- Please check the number of packaging bags, view the product installation manual and verify the product structure.
- Please check the direction of each part when unpacking them before installation.
- Please install the product patiently. Make sure each part is in the right position. Furniture is easy to assemble, but it needs patience and care to make every part in place.
- Please check the stability of the furniture after installation. Shake your furniture gently to confirm whether it is level with the ground or whether the screw is tight.
- Please keep the furniture open for a period of time to release residual painting smell.

Note:




Sunon 圣奥

Thanks for buying this product. Please read this instruction carefully before using.

Using instruction

Product introduction

Series : Balance series
 Model : DB78.18H, DB78.12H, DB78.09H, DB78.08H,
 DB78.18, DB78.12, DB78.09, DB78.08
 Name : Multi-functional table
 Dimension: 1800*750*750, 1200*750*750, 900*900*750,
 750*750*750, 1800*750*743, 1200*750*743,
 900*900*743, 750*750*743
 Color : Designated by orders
 Material : Fireproof veneer



This product and the decorative accessories are for office use.

Zhejiang Sunon Furniture Manufacture Co., Ltd
 Service Hotline: 4008-600-666
 Website: www.sunon-china.com
 Headquarters Address: Sunon Central Business Building, No. 200
 Citizen Street, Qianjiang CBD, Hangzhou, Zhejiang
 Manufacturing Base: No. 35, Ningdong Road, Economic and
 Technological Development Zone, Xiaoshan District, Hangzhou,
 Zhejiang
 Manufacturing Base: No. 6, Anren Road, Jianshan Economic and
 Technological Development Zone, Haining, Jiaxing, Zhejiang

Main features:

The product complies with the following standards:

GB 18580-2017 Limits on formaldehyde emission of indoor-decorative artificial panel and products made of it

GB/T 3324-2017 General technical requirements for wooden furniture

GB/T 3325-2017 General technical requirements for metal furniture

HJ 2547-2016 Technical requirements for environment-labeled products furniture

HJ 571-2010 Technical requirements for environment-labeled products artificial panel and products made of it

Warranty:

Product Warranty

Sunon strictly implements the national "three guarantees" policy (glass and mirror are not included). The warranty lasts one year (specials are not included), responses will be given within 24 hours.

- The warranty is only valid in China.
- Damage caused by improper use is not covered by the warranty.
- Damage caused by fire or a natural disaster is not covered by the warranty.

Step 1: Attach steel legs to the frame;

A					B				
/	frame+tabletop	1	4	35*725	steel leg	4			

Step 2: Use 6# Allen key to connect M8*45 screws with steel legs;

C					D				
M8*30	hexagon cylinder head screw	4	6#	Allen key	1				

Step 3: Tighten the screws one by one;

Step 4: Finish.

